

Washing Instructions  
PEQ 901- 903  
ESD COTTON LAB COATS

**Dry Cleaning (suggested):** Use Perchloroethylene only. Light ironing permitted.

**Laundry:** Maximum water temperature should not exceed 86°F (30°C).  
Use only neutral cleaners.

**Drying:** Hang at room temperature; never use tumble dry machine. Light ironing permitted.

Our Polyester-free special formulation, minimizes tribocharging effect giving the fabric a soft and light touch, which is very important during long working times.

PEQ fabric may be repetitively washed up to 50 times at 86° ( 30°) degrees without substantially degrading its ESD properties.